

# Maintenance of roof safety products

According to the Planning and Building Act (PBL) and the Act on Technical Requirements for Construction Works, inspections of roof safety devices must be carried out regularly. Weland Stål recommends that this is done annually. The purpose of the inspection is to detect faults and/or deficiencies that may arise due to weather, other damage or inadequate installation.

## Inspection points:

- The safety devices have been installed in accordance with Weland Stål's installation instructions.
- When supplementing individual roof safety installations, do not mix parts from different manufacturers.
- Deformed and/or damaged safety devices/fastenings must be replaced.
- Any paintwork damage on the products must be touched up to prevent corrosion. This does not apply to hot dipped galvanized or stainless steel products.
- Also check whether roof safety needs to be supplemented so roof work can be carried out in a healthy and safe environment (Swedish Work Environment Act, Chapter 2 § 2), even in the future.
- Where there is a risk of excess accumulation, snow guards must be cleared of snow.

Also check that the snow guards are correctly dimensioned for your particular snow zone using either the Weland Stål website or our catalogue.