


Part	Part. no.
1 ONE wire bracket	WL1337
2 ONE wire lock bolt kit	BS1300
3 Wire end bracket (terminated wire)	WL1002


Part	Part. no.
4 Bolt M10x20	BU1201/BU1200
5 Nut M10	MU1001/ MU1010

Check the wire to ensure that it has the blue Weland mark and that it is not damaged.




### 1. Fit ONE wire bracket

Fit a ONE wire bracket (1) to the gangway using 2 x bolts (4) + nuts (5) per bracket.




### 2. Fit ONE wire bracket as start

Place wire in ONE wire bracket (1), let out approx. 400 mm of wire and fold the bracket together. Secure using 1 x bolt (4).




### 3. Lock installation

Pull the wire back through the gangway. Thread on clamp tube (2), clamp securely in position. Secure to outgoing wire using two wire locks (2). Tighten the wire lock to a torque of 10 Nm.




### 4. Fit ONE wire bracket

Place wire in ONE wire bracket (1), tension the wire by pulling it by hand and fold the ONE wire bracket together. Secure using 1 x bolt (4).



### 5. Finish wire

Fit a ONE wire bracket (1) to the gangway using 2 x bolts (4) + nuts (5) per bracket.




### 6. Finish wire

Fit any wire runners. Place wire in ONE wire bracket (1), tension the wire by pulling it by hand and fold the ONE wire bracket together. Secure using 1 x bolt (4). Cut the wire approx. 400 mm from the bracket.


Part	Part. no.
1	ONE wire bracket
2	ONE wire lock bolt kit
3	Wire end bracket (terminated wire)

Part	Part. no.
4	Bolt M10x20
5	Nut M10




### 7. Finish wire

Pull the wire through the closest hole on the roof gangway to the outside of the gangway. Thread on clamp tube (2), clamp securely in position. Secure to the outgoing wire and two wire locks (2) at least 50 mm from the end of the wire. Tighten the wire lock to a torque of 10 Nm.



### 8. Wire with terminal

Fit end bracket (4) using 2 x bolts (5) + nuts (5). When fitting the last bracket, also fit any wire runners. Tension the wire so it does not sag. Secure by tightening the other nut.



### 9. Wire corners and transitions

Place a wire in a ONE wire bracket (1) and make a uniform hoop, ensuring that the runner runs freely. Place in the next ONE wire bracket (1) and secure using 1 x bolt (4).